

HƯỚNG DẪN CẤU HÌNH DSL-2750E HOẠT ĐỘNG NHƯ ACCESS POINT

LƯU Ý:

- Bài viết được thực hiện với DSL-2750E (HW: V1, FW: SEA_1.10) và PC.

1. CHUẨN BỊ:

- DSL-2750E được cấp nguồn điện và trạng thái sẵn sàng
- Kết nối internet qua dây mạng ethernet từ Router chính
- Router chính cấp địa chỉ IP tự động (DHCP)
- PC có kết nối mạng có dây/không dây
- Trình duyệt web Internet Explorer 7.0 trở lên

2. KẾT NỐI DÂY:

- dây mạng ethernet từ Router/Modem chính nối vào cổng LAN1 của DSL-2750E
- dây mạng ethernet nối cổng mạng trên PC với LAN4 của DSL-2750E.



3. CẤU HÌNH: sử dụng trang web cấu hình thiết bị

- Reset DSL-2750E về thiết lập mặc định: dùng vật nhọn nhấn và giữ nút Reset (bên dưới thiết bị) 15 giây
- Mở trình duyệt web, nhập vào ô địa chỉ <http://192.168.1.1>
- Đăng nhập:

LOGIN

Input username and password

Username : default username : admin

Password : default password : admin

Remember my login info. on this computer

Login

- **Tắt DHCP:**

Product Page: DSL-2750E Firmware Version:SEA_1.10

D-Link

DSL-2750E // **SETUP** ADVANCED MANAGEMENT STATUS HELP

Wizard
Internet Setup
Wireless
Local Network
LAN IPv6
Time and Date
Logout

LOCAL NETWORK

In this page, you can configure the local network settings of your router. Please note that settings in this page are optional and you need not change any of the settings in this page to get your network up and running.

ROUTER SETTINGS

The IP address of the router configured in this page is the one you use to access the Web management interface. If you change the IP address in this page, you need to adjust the network settings of your PC to access the network.

Router IP Address : 192.168.1.1
Subnet Mask : 255.255.255.0
Domain Name :
 Configure the second IP Address and Subnet Mask for LAN
IP Address :
Subnet Mask :

DHCP SETTINGS (OPTIONAL)

Enable DHCP Relay
Relay IP Address :

In this page, you can configure the built-in DHCP server to assign IP addresses to the computers on your network

DHCP SETTINGS (OPTIONAL)

Enable DHCP Relay
Relay IP Address :

In this page, you can configure the built-in DHCP server to assign IP addresses to the computers on your network.

Bỏ dấu check Enable DHCP Server

DHCP IP Address Range : to
DHCP IP Mask :
DHCP Router IP :
DHCP Lease Time : (seconds)

Use this section to configure the DHCP Server in lan and wlan port individual:

- LAN Port1
- LAN Port2
- LAN Port3
- LAN Port4
- WLAN Port1
- WLAN Port2
- WLAN Port3
- WLAN Port4

Apply Cancel