

HƯỚNG DẪN CẤU HÌNH DSL-2877AL HOẠT ĐỘNG NHƯ ACCESS POINT

LƯU Ý:

- Bài viết được thực hiện với DSL-2877AL (HW: A2, FW: 1.00.12SE) và PC.

1. CHUẨN BỊ:

- DSL-2877AL được cấp nguồn điện và trạng thái sẵn sàng
- Kết nối internet qua dây mạng ethernet từ Router chính
- Router chính cấp địa chỉ IP tự động (DHCP)
- PC có kết nối mạng có dây/không dây
- Trình duyệt web Internet Explorer 7.0 trở lên

2. KẾT NỐI DÂY:

- dây mạng ethernet từ Router/Modem chính nối vào cổng LAN4 của DSL-2877AL
- dây mạng ethernet nối cổng mạng trên PC với LAN1 của DSL-2877AL.



3. CẤU HÌNH: sử dụng trang web cấu hình thiết bị

- Reset DSL-2877AL về thiết lập mặc định: dùng vật nhọn nhấn và giữ nút Reset (phía sau thiết bị) 15 giây
- Mở trình duyệt web, nhập vào ô địa chỉ <http://192.168.1.1>
- Đăng nhập:

Product Page : DSL-2877AL Firmware Version : 1.00.12SE

D-Link

LOGIN

Login in to the router

Username :

Password :

Login

Mặc định:
Username: admin
Password: admin

BROADBAND

- Bỏ qua Setup Wizard:

Product Page : DSL-2877AL Firmware Version : 1.00.12SE

D-Link

WELCOME TO THE SETUP WIZARD

Welcome to the Setup Wizard:

- Step 1: Set your password
- Step 2: Select your Time Zone
- Step 3: Configure your internet connection
- Step 4: Name your Wireless Network
- Step 5: Secure your Wireless Network
- Step 6: Set your Wireless Security Password
- Step 7: Setup mydlink™ Cloud Services

Prev Next **Cancel** Connect

- Tắt DHCP:

DSL-2877AL	SETUP	ADVANCED	MAINTENANCE	STATUS	HELP
Wizard Internet Setup Wireless Setup LAN Setup 3G/4G Setup WAN Failover Priority Setup Time and Date IPv6RD mydlink™ Settings Internet Offline Reboot Logout	LOCAL NETWORK This section allows you to configure the local network settings of your router. Please note that this section is optional and you should not need to change any of the settings here to get your network up and running. ROUTER SETTINGS Use this section to configure the local network settings of your router. The IP Address that is configured here is the IP Address that you use to access the Web-based management interface. If you change the IP Address here, you may need to adjust your PC's network settings to access the network again. Router IP Address : 192.168.1.1 Subnet Mask : 255.255.255.0 IGMP Snooping : ☒ Activated ☐ Deactivated DHCP SETTINGS ☒ Disable DHCP Server : Choose this option. The IP address must be manually assigned on each device connected to device. ☐ Enable DHCP Server : Choose this option to setup as a DHCP server to distribute IP addresses to the LAN network. DHCP IP Address Range : 192.168.1.2 to 192.168.1.254 DHCP Lease Time : 1 Week IPV6 SETTINGS IPv6 Global Address : / Radvd Enable : ☒ Disable ☐ Enable DHCP6 Server : ☒ Disable ☐ Enable Apply	Helpful Hints.. These are the IP settings of the LAN interface for the Device. These settings may be referred to as Private settings. You may change the LAN IP address if needed. The LAN IP address is private to your internal network and cannot be seen on the Internet. If you already have a DHCP server on your network or are using static IP addresses on all the devices on your network, click on Disable DHCP Server to disable this feature. More...			

HẾT